

Attention! Beginning from firmware version 0.2.18 all customizations of embedded portal is necessary to make using source codes of portal. After all customizations complete it is necessary to make **compiling and minimization of source code** of portal. After compiling and minization all files of portal could be placed in home directory for further image making. Source code of portal (*portal-dev-*.tgz*) is in directory with current release <http://soft.infomir.com.ua>)

Disabling of "System settings"/"Settings". Disabling of entering to the embedded portal and other

This realizes while editing **rules.js** file. This files content the list of groups from sections "Settings", "System settings", "Loader (page 404)". Change value **true** to **false** to disable/hide any of that sections.

rules.js files is in next directories:

- /home/web/ - "Settigns";
- /home/web/system/settings - "System settings";
- /home/web/system/pages/loader - "Loader (page 404)".

/home/web/rules.js content:

```
/**  
 * Customization rules for manual tune  
 * @author DarkPark  
 * @namespace  
 */  
RULES = {  
  
    'Playback' : true,  
  
    'Interface' : true,  
  
    'AutoUpdateSoftware' : true,  
  
    'TimeShift' : true,  
  
    'SpeedTest' : true,  
  
    'SystemSettings' : true,  
  
    'SetupWizard' : true,  
  
    'DVB' : true
```

};

/home/web/system/settings/rules.js content:

```
/**  
 * Customization rules for manual tune  
 * @author DarkPark  
 * @namespace  
 */  
RULES = {  
    // Network  
    'Network' : true,  
    'Network/Wired(Ethernet)' : true,  
    'Network/Wired(Ethernet)/Auto(DHCP)' : true,  
    'Network/Wired(Ethernet)/Auto(DHCP),manualDNS' : true,  
    'Network/Wired(Ethernet)/Manual' : true,  
    'Network/Wired(Ethernet)/NoIP' : true,  
    'Network/PPPoE' : true,  
    'Network/PPPoE/Auto(DHCP)' : true,  
    'Network/PPPoE/Auto(DHCP),manualDNS' : true,  
    'Network/PPPoE/DisablePPPoE' : true,  
    'Network/Wireless(Wi-Fi)' : true,  
    'Network/Wireless(Wi-Fi)/Auto(DHCP)' : true,  
    'Network/Wireless(Wi-Fi)/Auto(DHCP),manualDNS' : true,  
    'Network/Wireless(Wi-Fi)/Manual' : true,  
  
    // Servers  
    'Servers' : true,  
    'Servers/General' : true,  
    'Servers/Portals' : true,  
    'Servers/Portals/More' : true,  
    'Servers/More' : true,  
  
    // Video  
    'Video' : true,  
    'Video/More' : true,  
  
    // Audio  
    'Audio' : true,  
    'Audio/More' : true,  
  
    // Advanced Settings  
    'AdvancedSettings' : true,  
    'AdvancedSettings/more' : true,  
  
    // Keyboard Layout  
    'KeyboardLayout' : true,
```

```
// Network Info
'NetworkInfo' : true,
'NetworkInfo/Wired(Ethernet)' : true,
- /home/web/system/settings/rules.js 1/68 1%
  'Network/PPPoE/DisablePPPoE' : true,
  'Network/Wireless(Wi-Fi)' : true,
  'Network/Wireless(Wi-Fi)/Auto(DHCP)' : true,
  'Network/Wireless(Wi-Fi)/Auto(DHCP),manualDNS' : true,
  'Network/Wireless(Wi-Fi)/Manual' : true,

// Servers
'Servers' : true,
'Servers/General' : true,
'Servers/Portals' : true,
'Servers/Portals/More' : true,
'Servers/More' : true,

// Video
'Video' : true,
'Video/More' : true,

// Audio
'Audio' : true,
'Audio/More' : true,

// Advanced Settings
'AdvancedSettings' : true,
'AdvancedSettings/more' : true,

// Keyboard Layout
'KeyboardLayout' : true,

// Network Info
'NetworkInfo' : true,
'NetworkInfo/Wired(Ethernet)' : true,
'NetworkInfo/PPPoE' : true,
'NetworkInfo/Wireless(Wi-Fi)' : true,

// Device Info
'DeviceInfo' : true,

// Reboot Portal
'RebootPortal' : true,

// Reboot Device
'RebootDevice' : true,

// Reset Settings
'ResetSettings' : true,

// Clear User Data
```

```
'ClearUserData' : true,  
  
    // Software Update  
    'SoftwareUpdate' : true  
};
```

/home/web/system/pages/loader/rules.js content:

```
/**  
 * Customization rules for manual tune  
 * @author DarkPark  
 * @namespace  
 */  
RULES = {  
    'portalsLoader/useExtPortalsPage' : true, // Allow 'MENU' button  
at loader page ( if 'false' you can't start portals loader page by pressing  
'MENU')  
    'portalsLoader/allowSystemSettings' : true, // Allow system  
settings at portals loader page  
    'page404/allowSystemSettings' : true, // Allow system  
settings at 404 page  
    'hidePortalsURL' : false, // Hide all portals  
URL at 404 page and portals loader page  
    'allowInnerPortal' : true // Allow inner portal  
at 404 page and portals loader page  
};
```

Set password for System Settings

- Enable [variable check](#)
- Add in system/variables/vars.ini variable **systemSettingsPassword=1234** where **1234** will be password to system settings.

From:
<https://docs.infomir.com.ua/> -

Permanent link:
https://docs.infomir.com.ua/doku.php?id=en:stb_webkit:faq:0.2.18:systemsettings_portaloader_etc



Last update: **2019/05/17 11:23**