

### To program the buttons do the following:

- Press the «On/Off» and «A/V» buttons at the same time and hold it for 2 seconds. When the green light of the «On/Off» button will stop blinking and will light steadily, it means the RC is ready to learn.
- Press the button you want to «teach» — the green light will start blinking.
- Place the infrared lamps of two RCs opposite each other and press the button on the RC of the other device, the function of which you wish to copy on AuraHD Plus RC. Hold for 2 seconds.
- After the green light two quick blinks you may continue programming other buttons.
- Repeat the procedure described above for all buttons you want to program for controlling external devices.
- Press the the «On/Off» and «A/V» buttons to save the programmed data; the green light should fade off .

### Reset

- Press **SETUP** and **OK** button at same time and **hold for 2 seconds** red LED will flash 5times. Reset is done.

**USING REMOTE CONTROL TO CONTROL THE DEVICE**

This section explains how to unpack Remote Control (RC) and prepare it for work. Your service provider can supply the product with an alternative RC. In that case please refer to the manual supplied by your service provider.

**Inserting batteries**

Remote Control requires two batteries type AAA, R03, LR03, UM-4, 286.

**Inserting batteries into Remote Control.**

Shift the battery cover located on back side of RC as shown in the picture.

Insert two batteries type AAA (included in package) taking care to observe the correct polarity as shown on RC.

Replace the battery cover as shown in the picture. Average lifetime of a batteries is about 1 year.

**Important information about using batteries**

Do not mix different types of battery or old and new batteries.  
Do not use rechargeable batteries with the remote control.  
Remove the batteries from the remote control if you are not going to use it for several weeks, to avoid the risk of leakage.  
Please respect your environment and any local regulations and dispose of old batteries in a responsible manner.

**Caution!** Do not attempt to recharge the batteries. Immediately remove any leaking batteries. Take care when handling leaking batteries as they may cause burns to the skin or eyes, or other physical injuries.

**Introduction into the Programmable Remote Control Unit**

MAG254 / MAG255 package includes a remote control with a special block of five programmable buttons (marked with blue print colour), which you may want to choose for controlling other devices (TV set, amplifier).

**To program the buttons do the following:**

Press the «On/Off» and «A/V» buttons at the same time and hold it for 2 seconds. When the green light of the «On/Off» button will stop blinking and will light steadily, it means the RC is ready to learn.

- Press the button you want to «teach» — the green light will start blinking.
- Place the infrared lamps of two RCs opposite each other and press the button on the RC of the other device, the function of which you wish to copy on device RC. Hold for 2 seconds.
- After the green light two quick blinks you may continue programming other buttons.
- Repeat the procedure described above for all buttons you want to program for controlling external devices.
- Press the the «On/Off» and «A/V» buttons to save the programmed data; the green light should fade off.

Programmable section (blue buttons)

Additional functions (red, green, yellow buttons)

Sound On/Off, A/V, Menu, Exit, Back, Info, Up, Down, Left, Right, Confirm, Volume, Change aspect ratio, To select a TV channel

- Turn the Media Player On / Off
- Change audio mode
- Setup menu
- Context menu
- Quick TV access
- TV Guide
- Virtual keyboard
- Skip
- Fast play
- Switch channels
- Play / Pause
- Stop
- Update

From: <https://docs.infomir.com.ua/> -

Permanent link: [https://docs.infomir.com.ua/doku.php?id=en:stb\\_webkit:remote\\_control\\_new\\_user\\_manual](https://docs.infomir.com.ua/doku.php?id=en:stb_webkit:remote_control_new_user_manual)

Last update: 2019/05/17 11:23

